




A **PLAYCORE** Company




Model # 236H-V8




SAFETY WARNINGS & EQUIPMENT INSPECTION

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severely worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediately.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user. NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.


HARDWARE



5/16" x 1"
Machine Bolt




5/16" Washer




5/16" Kep Nut


TOOLS REQUIRED




1/2" Wrench




1/2" Socket Wrench



Tape Measure



Level



Rubber Mallet

ULTRA SITE PRODUCT SPECIFICATIONS

236H-V8 8' ADA PICNIC TABLE WALK-THROUGH DESIGN

Top & Seats: 11 gauge die formed angle frame 1"x1-7/8" with 3" radius corners. 3/4" #9 steel expanded metal. 7 gauge x 1-1/2" flat bar center support and mounting bracket understructure. Electrically MIG welded.

Coating: Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.


Frame: 2" Square x 11 gauge pre-galvanized structural steel tubing. Cross braces 1" O.D. x 16 gauge pre-galvanized structural steel tubing. Brace attachment points 1-1/2"x1-1/2"x3/16" steel angle. Seat and top mounting points 7 gauge x 1-1/2" die stamped steel flat bar. All electrically MIG welded.

Frame Coating: Electrostatic powder coated application oven cured.

Hardware: All stainless steel hardware fasteners.

Dimensions: 8' ADA portable picnic table walk-through design. Top is 30" wide x 96" long and is 30-1/16" high. Seats are 12" wide x 72" long and 17-13/16" high. Outside to outside dimension is 67" x 96".


COMPONENTS



ITEM NO.	PartNo	DESCRIPTION	Qty.
1	01-04-0963	236 vinyl leg	2
2	T-V72-S	6' Expanded Seat	2
3	33-08-0004	1-5/8" 14-18 ga. round ribbed insert	12
4	T-V96H-T	8' H expanded Top	1
5	55-9565K38	2" square tube insert	8
6	P-01-04-0125	29 7/8" Brace	2
7	33-02-0007	5/16" SS Washer	48
8	33-03-0012	5/16" Kep Nut (SS)	28
9	33-05-0029	5/16" x 1" Machine Bolt (SS)	20
10	01-04-0967	236 leg end plate	2


Optional Surface Mount Hardware:
3/8" x 3-1/2" Concrete Expansion Anchor Bolts
(Not Included)

STEP 1




Install item #5 prior to installing table top and seats. Use specified hardware to install table top & seats

STEP 2



Install braces using specified hardware

STEP 3



Install item #10 using specified hardware. If surface mounting, insert item #3 after surface mounting and installing item #10

OVERALL DIMENSIONS

